Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden


Instruction No	Version	Part. No.
31269672	1.2	30744705, 31269666, 31269665

Rear view mirror, autodim, compass


Equipment

VIDA

IMG-242205



A0000162



IMG-330923

INTRODUCTION

Read through all of the instructions before starting installation.


Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.

Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.


In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

1



IMG-330954


2



IMG-330955

Applies to car with autodim


3



IMG-330956

Applies to all models


4



IMG-330957

Applies to car without autodim


5



IMG-330958

Applies to car without autodim


6



IMG-330959

Applies to car without autodim


7



IMG-330960

Applies to car without autodim


8



IMG-330961

Applies to car without autodim


9



IMG-330962

Applies to S40/V50 without autodim


10



IMG-330963

Applies to C30 without autodim


11



IMG-330964

Applies to car without autodim


12



IMG-330965

Applies to car without autodim


13



IMG-330966

Applies to car without autodim


14A



IMG-330967


Applies to all models

14B




IMG-330968

15



IMG-330969

16



IMG-330970

Reinstall the detached components in reverse order.

17



IMG-275777

Calibrate the compass. Information can be found in VIDA under:

Repair

Clean, check and adjust

8 Body and interior

88 Interior equipment

882 Interior equipment

Interior equipment

Compass calibration