Volvo Car Corporation Gothenburg, Sweden


Instruction No 32147432

Version 1.1 Part. No. 31650463, 32147429


Protective plate, beneath the engine

Special tools	
	981 4112 Drill
	Tool number:981 4112
	Tool description:Drill
	Tool boards:EU99
	951 2782 Rivet nut tool
	Tool number:951 2782
	Tool description:Rivet nut tool
	Tool boards:08

Materials	
Designation	Part number
Rust inhibitor, low viscosity	
Butyl tape	



Volvo Car Corporation Gothenburg, Sweden



IMG-462665

Volvo Car Corporation Gothenburg, Sweden

Information

1

Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.


Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

Color symbols

2



Note!


This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.

- Used for focused component, the component with which you will do something.
- 2. Used as extra colors when you need to show or differentiate additional parts.
- Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- 4. Used when the component is not fully removed from the vehicle but only hung to the side.
- 5. Used for standard tools and special tools.
- 6. Used as background color for vehicle components.

IMG-363036


Removal

Volvo Car Corporation Gothenburg, Sweden



- 1. Remove the screws.
- 2. Remove the clip.

The part is not to be reused.



Remove the marked part.

The part is not to be reused.

Accessory installation

Volvo Car Corporation Gothenburg, Sweden

IMG-452222

5


Warning!
Wear protective gloves.

Warning! Wear safety goggles.

Drill the holes.

Use special tool: T9814112, Drill

Applies to vehicles without predrilled holes.




Note!

Make marks with a centre punch for drilling.


Measure and mark out the centre.

Volvo Car Corporation Gothenburg, Sweden



Use a drill with the stated size


Drill first two layer only,use 5 mm drill



Use: , Rust inhibitor, low viscosity

Volvo Car Corporation Gothenburg, Sweden

Note! Orientation view




Use special tool: T9512782, Rivet nut tool

Reset the tool.

IMG-372305


IMG-452225

Volvo Car Corporation Gothenburg, Sweden



IMG-452625


12



Use hands only.

The outermost thread of the tool should be flush with the rivet $\operatorname{\mathsf{nut}}$ end.


Volvo Car Corporation Gothenburg, Sweden



Press the tool against the surface.

Hold the tool at right angles to the surface.

IMG-372295



Tighten to the value stated.


Volvo Car Corporation Gothenburg, Sweden

5 mm

Measure

Use: Vernier caliper

IMG-373060




Install components that come with the accessory kit.

Use: , Butyl tape

IMG-452704


Volvo Car Corporation Gothenburg, Sweden



Install components that come with the accessory kit.

Use: , Butyl tape


IMG-452726



Install components that come with the accessory kit.


Tightening torque: M6 , 10 Nm

Volvo Car Corporation Gothenburg, Sweden



Install components that come with the accessory kit.


Tightening torque: M8, 24 Nm



Install components that come with the accessory kit.

Tightening torque: M8 , 24 Nm

Volvo Car Corporation Gothenburg, Sweden



Tighten the bolts.

Installation

22

Reinstall the removed parts in reverse order.