
Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden


Instruction No	Version	Part. No.
30758077	1.0	30756499

Mesh pocket, cargo compartment, side panel



IMG-339771

Equipment




A0000162



IMG-239660



IMG-239681



IMG-339772

INTRODUCTION

Read through all of the instructions before starting installation.


Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.

Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

1



IMG-339778


Mesh pocket right side

Apply the strips of tape as illustrated.

Make marks for drilling holes for the mesh pocket mountings.

Drill out the hole.


2



IMG-339785

Insert the pocket's rear mounting in the hole in the panel and fold down.


3



IMG-339776

Insert the mesh pocket's front mounting towards the panel and lower end towards the floor.


4



IMG-339773

Move the front mounting to one side and drill the hole.


5



IMG-339774

Insert the front mounting in the panel and fold down the mesh pocket.


6



IMG-339775

Drill out the holes in the panel through the two clips.


7



IMG-339842

Tighten the mesh pocket's lower end

8



IMG-339781


Mesh pocket left side

Apply the strips of tape as illustrated.

Make marks for drilling holes for the mesh pocket mountings.

Drill out the hole.


9



IMG-339784

Insert the rear mounting in the panel and fold down the mesh pocket.

10




IMG-339783

Insert the mesh pocket's front mounting towards the panel and lower end towards the floor.

Mark the hole in the panel level with the middle of the radius of the bent wire frame.


11



IMG-339779

Move the front mounting to one side and drill the hole.


12



IMG-339782

Insert the front mounting in the panel and fold down the mesh pocket.

13




IMG-339805

Applies to vehicles with control module for electric handbrake.


Measure and place the clips in the wire frame. Measure between the rear edge panel and centre.

14



IMG-339804


15



IMG-339802

Remove the clips.

16




IMG-339806

Lift up the panel and check that the clips are positioned so that the control module and cable harness are not drilled. Move the clips if necessary.


Reinstall the panel.

17




IMG-339802

18



IMG-339803

19




IMG-339775

Applies to all models

Drill out the holes in the panel through the two clips.

20



IMG-339842

Tighten the mesh pocket's lower end.