

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden


Instruction No	Version	Part. No.
31339284	1.0	31339336

End pipes, single



IMG-357371

Equipment



IMG-345497



IMG-239664


Nm
lbf.ft



IMG-256903

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden



IMG-357372

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

Information

1

Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.


Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

Removal


2



IMG-319088

Use: Pipe cutter

3




IMG-319089

The part is not to be reused.


Accessory installation

4



IMG-319090

5




IMG-351061

Installation instructions, accessories


Volvo Car Corporation Gothenburg, Sweden

6



IMG-357387

7




IMG-351027

Installation instructions, accessories


Volvo Car Corporation Gothenburg, Sweden

8



IMG-319091

9




IMG-319092

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

10



IMG-351047

Tightening torque: M10 , 50 Nm