


Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

Instruction No 31408785
Version 1.0
Part. No. 31408784

Mudflaps, rear

Equipment



IMG-345497






IMG-263203



IMG-239664

Nm
lbf.ft



x6

IMG-422808

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

Information

1

Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.


Ensure that all tools stated in the instructions are available before starting installation.

Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

Color symbols

2



IMG-363036

Note!

This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.


1. Used for focused component, the component with which you will do something.
2. Used as extra colors when you need to show or differentiate additional parts.
3. Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
4. Used when the component is not fully removed from the vehicle but only hung to the side.
5. Used for standard tools and special tools.
6. Used as background color for vehicle components.

Removal

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden


3



IMG-422870

Remove the marked part.

4




IMG-422878

Clean the surface.

Installation instructions, accessories

Volvo Car Corporation Gothenburg, Sweden

5




IMG-422879

Remove the screws.

Accessory installation

6




IMG-422881

Install component that comes with the accessory kit.

Check

Installation instructions, accessories


Volvo Car Corporation Gothenburg, Sweden



IMG-422884

8 Repeat all method steps for the other side.

Installation



IMG-405228

Note!
Make sure to follow the sequence indicated.

Tightening torque: Aluminum wheel rim to wheel hub
Stage 1: 4 Nm
Stage 2: 50 Nm
Stage 3: 140 Nm