
Volvo Car Corporation Gothenburg, Sweden

Instruction No 31373271 Version 1.0 Part. No.


31399333, 31399334, 31399335

End pipes, double, integrated





Volvo Car Corporation Gothenburg, Sweden



IMG-378474

Volvo Car Corporation Gothenburg, Sweden

Information Read through all of the instructions before starting installation. Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation. Ensure that all tools stated in the instructions are available before starting installation.


Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.

Color symbols

2

1



Note!

This colour chart displays (in colour print and electronic version) the importance of the different colours used in the images of the method steps.


- Used for focused component, the component with which you will do something.
- 2. Used as extra colors when you need to show or differentiate additional parts.
- Used for attachments that are to be removed/installed. May be screws, clips, connectors, etc.
- 4. Used when the component is not fully removed from the vehicle but only hung to the side.
- 5. Used for standard tools and special tools.
- 6. Used as background color for vehicle components.


IMG-363036

Removal


Applies to vehicles with single end pipe

Volvo Car Corporation Gothenburg, Sweden







Volvo Car Corporation Gothenburg, Sweden




Use: Pipe cutter




Volvo Car Corporation Gothenburg, Sweden






Volvo Car Corporation Gothenburg, Sweden





Accessory installation



Volvo Car Corporation Gothenburg, Sweden


11






IMG-378510

Volvo Car Corporation Gothenburg, Sweden





IMG-338862






Volvo Car Corporation Gothenburg, Sweden






Volvo Car Corporation Gothenburg, Sweden





Tightening torque: M10 , 50 Nm



Note!
The Diffuser (accessory) must be installed on the vehicle.

Volvo Car Corporation Gothenburg, Sweden






On both sides.

Tightening torque: M10, 50 Nm


Removal

Applies to vehicles with double end pipe

Volvo Car Corporation Gothenburg, Sweden



Use: Pipe cutter



Use: Pipe cutter


Accessory installation

Volvo Car Corporation Gothenburg, Sweden


IMG-378326

23

Note!
The Diffuser (accessory) must be installed on the vehicle.



Volvo Car Corporation Gothenburg, Sweden



On both sides.

Tightening torque: M10, 50 Nm