
Volvo Car Corporation Gothenburg, Sweden

 Instruction No
 Version
 Part. No.

 31316266
 1.1
 30758112, 30758111, 30758110, 30758114


End pipes, double



A0000162

IMG-256903

Volvo Car Corporation Gothenburg, Sweden



IMG-338901

Volvo Car Corporation Gothenburg, Sweden

INTRODUCTION


Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.

Ensure that all tools stated in the instructions are available before starting installation.


Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.




Locate the marking on the exhaust pipe.

Applies to vehicles with 6-cylinder engine




Volvo Car Corporation Gothenburg, Sweden




Applies to vehicles with 4-cyl and 5-cyl engines


Volvo Car Corporation Gothenburg, Sweden




4C



Volvo Car Corporation Gothenburg, Sweden






Applies to all models


Get help from a colleague for this procedure.

Volvo Car Corporation Gothenburg, Sweden



Get help from a colleague for this procedure.

Volvo Car Corporation Gothenburg, Sweden



Illustrations A, B and C


Get help from a colleague for this procedure.

Applies to vehicles with 4-cyl and 5-cyl engines Applies to vehicles with 6-cylinder engine


IMG-338862



8C



Volvo Car Corporation Gothenburg, Sweden



Applies to all models