

Volvo Car Corporation Gothenburg, Sweden

 Instruction No
 Version
 Part. No.


 31256267
 1.2
 31259377, 31259376, 31259341, 31259407, 31259339, 31259373, 31259409, 31259372, 31259408, 31259342, 31259406, 31259340, 31259340, 31259086, 31259085, 30756902, 30756901


Gear shift knob





Volvo Car Corporation Gothenburg, Sweden





IMG-233442

Volvo Car Corporation Gothenburg, Sweden

Any comments on this publication? Please contact your nearest retailer. Thank You!		
Publ.no:	Issue:	Kit no:
Comments:		
From:		
Address:		
Telephone:		
Telefax:		

IMG-213320

Volvo Car Corporation Gothenburg, Sweden

INTRODUCTION


Read through all of the instructions before starting installation.

Notifications and warning texts are for your safety and to minimise the risk of something breaking during installation.

Ensure that all tools stated in the instructions are available before starting installation.


Certain steps in the instructions are only presented in the form of images. Explanatory text is also given for more complicated steps.

In the event of any problems with the instructions or the accessory, contact your local Volvo dealer.




Steps 1-7 apply to cars with automatic transmission

Turn the locking sleeve on the gear selector lever knob a quarter turn clockwise.




Pull the locking sleeve downwards.

Volvo Car Corporation Gothenburg, Sweden




Pry out the 2 x catches at the front and rear edge using a small screwdriver.




Volvo Car Corporation Gothenburg, Sweden

5




Install the new gear shift knob (A) by first pressing in the lock button (1). Then push it down (2) until the catches engage.



Move the locking sleeve up over the catches.


Volvo Car Corporation Gothenburg, Sweden



Turn the locking sleeve on the gear selector lever knob a quarter turn counter-clockwise.

Warning!


Check that the Shift-Lock function works.




Steps 8-12 apply to cars with manual transmissions

Grasp the locking ring that is located under the gear selector lever knob and before the boot. Work loose slightly and pull the locking sleeve and boot down. Take care so that the boot does not jump out of the locking ring.

Volvo Car Corporation Gothenburg, Sweden




Pry out the 2 x catches on the side using a small screwdriver.




Pull the gear selector lever knob straight up.

Volvo Car Corporation Gothenburg, Sweden



Install the new gear selector lever knob.

Press downwards until all the catches engage.



Move the boot and locking ring up so that the locking ring hooks into the gear selector lever knob.